

ENVIRONMENT HEALTH & SAFETY

Formaldehyde emissions

Pure Paper has formaldehyde emission levels of less than 0.13mg/m³ = **E1**.

Volatile Organic Compounds – Low VOC's

Health and Safety

As in all wood working operations, it is essential that adequate protection is taken against the contact and the breathing of laminate dust when processing, and that normal workplace hygiene and safety practices are followed.