

ENVIRONMENT HEALTH & SAFETY

Formaldehyde emissions

Pure Paper has formaldehyde emission levels of less than 0.13mg/m³ = E1.

Download [Pure Paper VOCs and Formaldehyde Emissions Report](#)

Volatile Organic Compounds – Low VOC's

Download [Pure Paper VOCs and Formaldehyde Emissions Report](#)

Health and Safety

As in all wood working operations, it is essential that adequate protection is taken against the contact and the breathing of laminate dust when processing, and that normal workplace hygiene and safety practices are followed.

- Download [Material Safety Data Sheet Pure Paper Color Laminates](#)
- Download [Material Safety Data Sheet Pure Paper Metal Laminates](#)