

BRIGGS VENEERS

Special, Burl & Exotic Wood Veneers

ENVIRONMENT HEALTH & SAFETY

Health, Safety, Formaldehyde, VOC's

Natural wood veneer in its raw state has no added formaldehyde and formaldehyde emissions are well below Super E0 which is 0.03 ppm (lower than E0). Additionally it should be noted that wood veneer is exempt from Formaldehyde emissions section of the Greenstar tools: see "[Formaldehyde Statement Natural Timber Veneer](#)". Raw veneer has negligible VOC's (volatile organic compounds). Any contribution to VOC's and formaldehyde in veneered panels is not generally due to natural veneer, but due to the substrate, glues and coating. If the *finished veneer panels* are required to be E0 and low VOC, please specify all substrates, glues and coatings to be E0 and Low VOC.

FSC® & PEFC™ certified veneers

Briggs offers a number of these veneers as independently certified to be from well-managed forests under the FSC® and PEFC™ forest management schemes. See the [eco-cert range](#) of FSC® and PEFC™ veneers. Briggs holds current PEFC™ and FSC® Chain of Custody certificates.

As in all wood working operations, it is essential that adequate protection is taken against the contact and the breathing of wood dust when processing, and that normal workplace hygiene practices are followed.

Download [Briggs FSC® Chain of Custody Certificate](#)

Download [PEFC™ Chain of Custody Certificate](#)

Download [Material Safety Data Sheet Veneer](#)